

Airglas, Inc.
**INSTALLATION, MAINTENANCE AND INSTRUCTIONS FOR CONTINUED
AIRWORTHINESS (ICA) MANUAL EB-170-105**

**INSTALLATION, MAINTENANCE
AND
INSTRUCTIONS FOR CONTINUED AIRWORTHINESS (ICA)
for
170EB
All Composite Extended Baggage
Installed in Cessna 100 Series Aircraft**

Document No: EB-170-105

Date: June 17, 2015

Revision: C

This document and the information disclosed herein are proprietary information of Airglas, Inc. ®. Neither this document nor the information contained herein shall be transmitted, reproduced, copied, or disclosed in any form or by any means without the written authorization Airglas, Inc. ®. The information disclosed herein includes trade secrets and confidential business and/or financial information and falls within exemption (b) (4) of 5 USC 552 (FOIA) and the prohibitions of 18 USC 1905.

Airglas, Inc.
INSTALLATION, MAINTENANCE AND INSTRUCTIONS FOR CONTINUED
AIRWORTHINESS (ICA) MANUAL EB-170-105

AIRWORTHINESS LIMITATIONS

The Airworthiness Limitations section is FAA approved and specifies maintenance required under §§43.16 and 91.403 of the Federal Aviation Regulations unless an alternative program has been FAA approved.

No additional airworthiness limitations apply.

LOG OF REVISIONS

| Revision | Pages Affected | Description | By | Date |
|-----------------|-----------------------|----------------------------------------------------------------------------------------------------------------------|-----------|-------------|
| Original | | Original Document | CDB | 05/29/2013 |
| A | 4, 5 | Added note regarding baggage shelf. Removed 170 and 170A models. | CDB | 01/15/2014 |
| B | 4 | Added psi loading limitation. | CDB | 03/21/2014 |
| C | 5, 6, 7 | Revised installation steps 2, 8, 11, and 13. Added kit weight to section 8. Revised log of revisions column 4 title. | CDB | 06/17/2015 |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

Distribution of Changes

A current copy of this manual will be available on the **Airglas, Inc.**®

web-site available for download.

Airglas, Inc.
**INSTALLATION, MAINTENANCE AND INSTRUCTIONS FOR CONTINUED
AIRWORTHINESS (ICA) MANUAL EB-170-105**

Table of Contents

| <u>SECTION</u> | <u>DESCRIPTION</u> | <u>PAGE</u> |
|-----------------------|-----------------------------------|--------------------|
| | Cover Page | 1 |
| | Log of Revisions | 2 |
| | Table of Contents | 3 |
| 1.0 | Specifications | 4 |
| 2.0 | Limitations | 4 |
| 3.0 | Airplane Installation Eligibility | 4 |
| 4.0 | Required Equipment | 4 |
| 5.0 | Initial Installation | 5-6 |
| 6.0 | Removal | 6 |
| 7.0 | Re-installation | 6-7 |
| 8.0 | Weight and Balance | 7 |
| 9.0 | Scheduled Inspection | 7-8 |

Airglas, Inc.
**INSTALLATION, MAINTENANCE AND INSTRUCTIONS FOR CONTINUED
AIRWORTHINESS (ICA) MANUAL EB-170-105**

1.0 Specifications:

The 170EB is an all composite extended baggage for installation in the aft fuselage of Cessna 170B aircraft between fuselage station 108 and fuselage station 140. The baggage kit contains a floor panel (P/N 2004-2) and an aft bulkhead (P/N 2004-1). The baggage area is limited to 50 lbs. of baggage.

2.0 Limitations:

The 170EB installation is limited to:

- a) Maximum baggage weight of 50 lbs.
- b) Maximum loading is 50 pounds per square foot.
- c) A cargo net (Cessna P/N 2015009-3 or equivalent) is required for installation.

3.0 Airplane Installation Eligibility

The 170EB is approved for installation in Cessna aircraft model 170B.

4.0 Required Equipment:

- a) Cordless drill.
- b) 3/16" drill bit.
- c) Rivnut® installation tool.
- d) #2 Phillips screwdriver.
- e) Small round file.
- f) Adjustable open end wrench.
- g) 3/8" wrench.
- h) 3M® Super 77 (or equivalent) spray adhesive.
- i) Dust mask.
- j) Vacuum

CAUTION: These parts are constructed of carbon fiber and epoxy. Carbon fiber dust is hazardous to your respiratory system. Wear approved dust mask or respirator. Vacuum up all dust and/or wipe up with damp paper towel to keep it from getting airborne.

Airglas, Inc.

**INSTALLATION, MAINTENANCE AND INSTRUCTIONS FOR CONTINUED
AIRWORTHINESS (ICA) MANUAL EB-170-105**

5.0 Initial Installation:

(Note: If baggage shelf assembly is retained, omit step 2)

| | |
|------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1. | Remove fuselage interior panels to expose the front side of the bulkhead assembly @ fuselage station (F.S.) 108. |
| 2. (SEE NOTE ABOVE) | Remove the headliner from the stringer that goes across the middle of the opening in the bulkhead assembly @ F.S.108. Remove the stringer from across the middle and the doublers on both sides of the opening in F.S.108 by drilling out the rivets that attach them to the bulkhead assembly (See Note 3 on Installation Dwg. #2004-3). Trim the headliner material so that it wraps around the bulkhead assembly and glue it to the aft side of the bulkhead assembly using 3M Super 77 spray adhesive or equivalent. |
| 3. | Take the composite bulkhead (P/N2004-1) and place it against the FWD side of the bulkhead assembly @ F.S.140 (See Notes 2 and 4 on installation drawing 2004-3). |
| 4. | Using the composite bulkhead as a template, mark and drill six mounting holes in the F.S.140 bulkhead assembly with a 1/4" drill bit. |
| 5. | Remove the composite bulkhead and install six (6) size A10-80 B.F. Goodrich Rivnuts® provided, one in each of the six mounting holes (See Note: 4 on Installation Dwg. #2004-3 for optional anchor nuts). |
| 6. | Measure and mark the locations for two (2) D-rings on the F.S.140 bulkhead assembly (Ref.: Detail 1 on installation drawing). Drill the holes using a 3/16" drill bit, and install 2 D-rings using 2 (ea.) AN525-10R9 screws, AN970-3 washers, and an AN365-1032 lock nuts. (Ref.: section B-B on installation drawing) |
| 7. | Install the composite bulkhead on the F.S. 140 bulkhead assembly using six (6) AN526-1032R8 recessed truss head screws provided. |
| 8. | Set the floor panel (P/N 2004-2) in place so that it rests on the bottom flanges of the F.S. 108 and composite bulkhead flange. Using the floor panel as a template, mark the four hole locations in F.S. 108 doubler using a pencil. Confirm the new holes will use existing holes or have at least 2 diameters edge distance to existing holes (SEE NOTE BELOW). Drill seven (7) mounting holes in the bulkhead assemblies (4 in F.S. 108 doubler – 3 in the composite bulkhead flange) using a 1/4" drill bit. Remove the floor panel and install seven (7) size A10-80 B.F. Goodrich Rivnuts®, one in each of the mounting holes. |

Airglas, Inc.

**INSTALLATION, MAINTENANCE AND INSTRUCTIONS FOR CONTINUED
AIRWORTHINESS (ICA) MANUAL EB-170-105**

5.0 Initial Installation-Continued:

| | | |
|-------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------|
| 9. | Install the composite floor panel using seven (7) AN526-1032R8 recessed truss head screws. | |
| 10. | Measure and mark the locations for two (2) D-rings on the F.S.108 bulkhead assembly (Ref.: Detail 1 on installation drawing). Drill the holes using a 3/16” drill bit, and install 2 D-rings using 2 (ea.) AN525-10R9 screws, AN970-3 washers, and an AN365-1032 lock nuts. (Ref.: section B-B on installation drawing) | |
| 11. | Install the following placard is required to be located on the face of the bulkhead assembly at fuselage station 108. <table border="1" data-bbox="706 646 1312 800"><tr><td>50 POUND MAXIMUM LOAD REFER TO WEIGHT & BALANCE DATA FOR BAGGAGE/CARGO LOADING</td></tr></table> | 50 POUND MAXIMUM LOAD REFER TO WEIGHT & BALANCE DATA FOR BAGGAGE/CARGO LOADING |
| 50 POUND MAXIMUM LOAD REFER TO WEIGHT & BALANCE DATA FOR BAGGAGE/CARGO LOADING | | |
| 12. | Ensure that a cargo net (Cessna P/N 2015009-3 or equivalent) is available for utilization in the aircraft. | |
| 13. | Revise aircraft weight and balance and equipment list. Place a copy of AFMS-170EB in aircraft flight manual. | |
| 14. | Prepare and file FAA form 337. | |

Note: If needed, relocate holes ensuring hole centers are at least 2 diameters from edge of part, or adjacent holes.

6.0 Removal:

| | |
|----|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1. | Remove the seven (7) AN526-1032R8 recessed truss head screws securing the floor panel (P/N 2004-2) to the aircraft. Remove floor panel from aircraft. (Ref: 4Installation Dwg. #2004-3) |
| 2. | Remove the six (6) AN526-1032R8 recessed truss head screws securing the composite bulkhead (P/N 2004-1) on the F.S. 140 bulkhead assembly. Remove composite bulkhead from aircraft. (Ref: Installation Dwg. #2004-3) |

7.0 Re-installation:

| | |
|----|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1. | Install the composite bulkhead (P/N 2004-1) in the aircraft on the F.S. 140 bulkhead using six (6) AN526-1032R8 recessed truss head screws. (Ref: Installation Dwg. #2004-3) |
|----|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

Airglas, Inc.

INSTALLATION, MAINTENANCE AND INSTRUCTIONS FOR CONTINUED AIRWORTHINESS (ICA) MANUAL EB-170-105

7.0 Re-installation-Continued:

| | |
|----|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 2. | Install the floor panel (P/N 2004-2) in the aircraft between F.S. 108 and F. S.140 using seven (7) AN526-1032R8 recessed truss head screws. (Ref: Installation Dwg. #2004-3) |
|----|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

8.0 Weight and Balance:

Baggage kit weighs 5.5 lbs. but due to production variability, use actual weight of installed components.

| Component | Weight | Arm |
|------------------|---------------|------------|
| 170EB | | +124 |
| | | |

9.0 Scheduled Inspection:

At each annual or 100 hour inspection, or when damage occurs; inspect as follows:

- a) Installation Inspection: Remove the extended baggage and inspect all aluminum mounting surfaces for possible corrosion. If corrosion is detected, treat and/or repair in accordance with AC43.13-1B or the appropriate Cessna Service Manual.
- b) Composite Bulkhead Inspection: Inspect the bulkhead for cracks, gouges, scrapes or punctures. None are permitted within 3” of the bottom flange. Gouges and scrapes less than 2” long are permitted elsewhere. For any damage that exceeds these limits, either replace the bulkhead with a serviceable bulkhead or contact the manufacturer for proper repair procedures.
- c) Composite Floor Inspection: No scrapes, gouges, cracks, or punctures are permitted in the side flanges and within 3” of the flanges. Scrapes and gouges less than 2” long are permitted elsewhere. Punctures less than 1” are allowed in the center. For any damage that exceeds these limits, either replace the floor with a serviceable floor or contact the manufacturer for proper repair procedures.

Definitions:

Scratch- A mark on the painted surface that does not penetrate the paint, into the carbon fiber material.

Scrape- Penetrates the paint but does not disturb or break the carbon fiber material.

Airglas, Inc.
**INSTALLATION, MAINTENANCE AND INSTRUCTIONS FOR CONTINUED
AIRWORTHINESS (ICA) MANUAL EB-170-105**

9.0 Scheduled Inspection-Continued:

Definitions-Continued:

Gouge- Damages the carbon fiber material but is not detected on the back side.

Puncture- Damages the carbon fiber material and is detectable on the back side.

--END--