

AIRGLAS, INC.

Data Plate Placard Application Instructions

(Install at room temperature)

1. Install in location depicted on installation drawing.
2. Mask area around placard location.
3. Scuff surface of ski at same size as placard.
4. Wash area with acetone.
5. Odd serial number represents left-hand ski when applicable.
6. Form placard by hand to match ski contour.
7. Remove paper backing from placard.
8. Apply thin layer 5 minute epoxy to ski and placard.
9. Apply placard to ski.
10. Hold in place (clamp or weight).
11. Before epoxy sets fully remove excess squeeze out with acetone soaked rag and plastic scraper.
12. Allow to cure for a minimum of 20 minutes before removing clamp.
13. Remove masking tape.

